

# 9200 Series Accessories

## Manual Operators

Number	
9210	Lever Control for Adjust-O-Vent™ and Adjustable Louvers; one required per section.
9220	Damper push-pull control with thumbscrew; connects to damper frame and therefore must be adjusted in the airstream. One required on each section.
9231	Chain operator with 10 feet of chain.
9232	Chain operator with 20 feet of chain
9233	Chain operator with 30 feet of chain.
9234	Chain operator with 40 feet of chain.
9240	Fusible Fire Link & Spring Operator. (Adj. Louvers and Control Dampers.)
9241	ELT Link & Spring Operator. (Adj. Louvers and Control Dampers.)
9250	Hand quadrant for control dampers; 1/2' dia. damper shaft extension.
9251	Stainless Steel Hand quadrant. Similar to 9250 except stainless construction
9261	Crank Operator, worm gear on Heavy-duty aluminum housing. One required per section, up to 30 sq. ft.

**NOTE: REFER TO VENT PRODUCTS FORM 2970 AND 5970 FOR ABOVE MANUAL OPERATOR DETAILS**